

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



444 Reading Road
Cincinnati, Ohio 45202
800-543-0488
513-241-1855 fax

Copyright ©The VERDIN Company 2007



VERDIN 3200 Control

- Daylight Savings Time Change Instructions -

Step 1
Press
'C 6'



PREVIOUS
STEP

NEXT
STEP


MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 2
Press
'# 1'



VERDIN 3200 Control

- Daylight Savings Time Change Instructions -

Step 3
Press The
'Down Arrow'
Once, So Hours
are Blinking



PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 4
Enter Correct
Hour Using The
'# Buttons'

PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 5
Enter Correct
Minutes Using
The '# Buttons'

PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 6
Enter Correct
Seconds Using
The '# Buttons'



VERDIN 3200 Control

- Daylight Savings Time Change Instructions -

Step 7
Press
'ESC'



PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions

Step 8
Use The 'Right'
Arrow To
Change 'No &
Yes'



PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 9
Press
'OK'



VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 10
Press 'ESC'
Once To Go
Back To The
Main Display

PREVIOUS
STEP

NEXT
STEP

MAIN
MENU

VERDIN 3200 Control

- Daylight Savings Time Change Instructions -



Step 11
Finished

PREVIOUS
STEP

MAIN
MENU