

# VERDIN VPC 50 & Afford-A-Bell Controllers

## - Daylight Savings Time Change Instructions -




444 Reading Road  
Cincinnati, Ohio 45202  
800-543-0488  
513-241-1855 fax

Copyright ©The VERDIN Company 2007

# VERDIN VPC 50 & Afford-A-Bell Controllers

- Daylight Savings Time Change Instructions -



Step 1  
Tap the  
'Menu' key

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -




Step 2  
Tap the  
'Advanced' key

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -




Step 3  
Tap the  
'Quit' key

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 4  
Tap the  
line that has  
the Day of the  
Week, Month  
and Date

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -




Step 5  
Tap the  
line that has  
the time zone

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 6  
Scroll down  
and select the  
line with  
'GMT-7'  
(note – this  
selection is the  
correct selection for  
all time zones in  
the US and  
Canada)

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 7  
Select 'GMT-7  
Arizona' and  
tap OK  
(Note: This is the  
correct selection for  
all time zones in  
the US and  
Canada)

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 8  
Tap 'Yes'

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 9  
You are now  
back at the  
windows  
screen...  
Please  
continue

# VERDIN VPC 50 & Afford-A-Bell Controllers


- Daylight Savings Time Change Instructions -



Step 10  
Press Button

# VERDIN VPC 50 & Afford-A-Bell Controllers


- Daylight Savings Time Change Instructions -



Step 11  
Tap 'Menu'


# VERDIN VPC 50 & Afford-A-Bell Controllers

- Daylight Savings Time Change Instructions -




Step 12  
Tap  
'Set Clock'

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -




Step 13  
Tap the hours  
and highlight

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -




Step 14  
Use the  
'Up / Down'  
arrows to set  
for correct time

## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 15  
Tap the  
minutes and  
highlight


## VERDIN VPC 50 & Afford-A-Bell Controllers - Daylight Savings Time Change Instructions -



Step 16  
Use the  
'Up / Down'  
arrows to set  
for correct time

# VERDIN VPC 50 & Afford-A-Bell Controllers


## - Daylight Savings Time Change Instructions -



Step 17  
Tap 'Set'

# VERDIN VPC 50 & Afford-A-Bell Controllers


## - Daylight Savings Time Change Instructions -



Step 18  
Tap 'OK'

# VERDIN VPC 50 & Afford-A-Bell Controllers

- Daylight Savings Time Change Instructions -



Finished